


RAYMARINE FLUXGATE COMPASS INSTALLATION GUIDE

Raymarine®
www.raymarine.com

Parts supplied



Fluxgate compass
with 8 m (26 ft) cable




Compass
warning label



No8 x 3/4 inch pan-head
self-tapping screws (x4)


Tools Required



Power Drill



3 mm (1/8 inch) drill



Pozi-drive
screwdriver





D6268-1




Non-magnetic hulls
Coques non magnétiques
Aluminium-Rümpfe
Cascos no magnéticos
Scafi non magnetici






Magnetic hulls
Coques magnétiques
Stahlrümpfe
Cascos magnéticos
Scafi magnetici



D6270-1




Min 1m (3ft 3in)



D6271-1

1.




↑
Vertical



D6272-1


2.



↑
Vertical

D6273-1


3.



D6274-1



Refer to Autopilot Manual
 Se référer au manuel de pilote automatique
 Siehe Handbuch Autopilot
 Refiérase al manual del piloto
 Fare riferimento al manuale dell'autopilota



D6275-1



Raymarine Ltd, Portsmouth, Hampshire, UK PO3 5TD
 Raymarine Inc. Nashua, NH 03063-4219, USA
 Recyclable Material - Please dispose of responsibly.

+44 (0) 23 9269 4713
 Toll Free: 800-539-5539
 +1 603-881-5200